

# BORGOO



## 佛山市首冠电器有限公司

地址：广东省佛山市南海区里水镇邓岗北牌村西门工业区北面1号厂房

香港办公地址：香港长沙湾长裕街10号利行工业大厦1楼108室

Foshan Shouguan Electrics Co., Ltd.

ADD : No.1 North, Ximen Industrial Zone, Beiyu village, Denggang, Lishui town, Nanhai District, Foshan City, Guangdong Province, China

HK ADD : Unit108,1/F, Lee Hang Industrial Building, 10 Cheung Yue Street,

Cheung Sha Wan, Kowloon, HK

TEL : 86-0757-85606277 85613883

FAX : 86-0757-85613883

[www.borgoo.com](http://www.borgoo.com)

佛山市首冠电器有限公司保留更改产品设计与规格的权利，如有变动，恕不另行通知

## 榨汁机 BJ-800

## 使用说明书

## 目 录

2	产品简介
2	产品特点
3	构件说明
3	注意事项
5	操作指南
9	清洁及保养
11	疑难解答
12	技术规格参数
12	执行标准
12	果汁食谱
14	英文版说明书


## 产品简介

感谢您的选择，欢迎光临博格利佳。BJ-800高效能榨汁机采用特细双层刀网专利技术，具有双重榨汁、双重过滤的特性，为您轻松榨出大量的果汁。超大加料管，超大容量，易拆洗的结构，健康果汁轻松制作。

## 产品特点

1. 不锈钢外壳，美观耐用。
2. 专利特细不锈钢过滤网，实现双重榨汁双重过滤。
3. 出汁率超过80%，比传统榨汁机提高30%。
4. 75mm超大加料管可容下整个水果和蔬菜。
5. 独特倾斜角度设计，出汁口可倒出大量的汁液
6. 两种速度档位设定，配合软果和坚果制作需要。
7. 1.5升果渣储藏罐，配合700ml果汁杯，超大容量方便使用。
8. 人性化的拆装结构，更便于清洗。
9. 安全保护装置，自动断电，延长机器使用寿命。
10. 获得3C、GS、CE、CB、CUL等多项国内外认证。

## 构件说明



- 1-4/6-8是可拆卸清洗的部分，
- 5&11是不可拆卸的固定零件，
- 9&10是不可拆卸，需要操作的零件。
- 0= 关    1=低档    2= 高档

## 注意事项

使用BJ800高效能榨汁机之前，请仔细阅读本说明书并妥善保管，以供日后参考。为防止给使用者或他人带来危害或损害，请务必遵守以下基本安全防护措施。

## 危险

不要把电源线、插头或机器浸入水或任何其他液体中，避免电击伤害。

## 警告

1. 不建议由身体、感官、精神有缺陷者或是经验、认知欠缺者使用本机器，以免发生意外。
2. 不允许儿童使用本机器，在儿童附近使用本机器时必须严密看管。否则会有被割伤、触电等危险。
3. 操作或清洗滤网时，请注意滤网上的锋利刀片，避免割伤。
4. 始终使用推棒将蔬果推进入料口，切勿接触刀片，以避免割伤。若进料口阻塞，请用推料棒将阻塞物推下去。如果此方法不能奏效，请关机并拔除电源插头后再拆解机器清除阻塞物。
5. 如果发现刀片或滤网有破损，请勿使用本机器，否则可能导致机身损坏或其他意外。
6. 电源线、插头损伤时或其他部件松动时，请勿使用本机器，否则会有造成触电、短路、起火的危险。
7. 机器跌落到任何液体中或因跌落造成损坏时，请勿操作机器。否则可能导致机身损坏或其他意外。请将机器送到博格利佳品牌指定维修点进行检测和维修。
8. 本机器电源软线采用“Y”型连接，如果电源软线损坏，为避免危险，请将机器送到博格利佳品牌指定维修点进行检测和维修。
9. 请勿使用非本公司配置或推荐的附件，否则可能造成起火、电击或其他伤害，同时您的质量保证书将会失效。

## 注意

1. 请总是在干燥的水平面使用本产品。
2. 机器使用时必须有人看管，否则可能导致意外。
3. 无人看管或使用完毕时，请将机器关闭并拔除电源插头，避免造成意外。
4. 请勿在室外使用本机器，以免导致机器过快老化。
5. 本机器仅供家用，请勿用于其他用途。
6. 拆装部件和清洁机器时，请拔除电源插头，避免造成触电。
7. 在马达转动前必须保证榨汁盖已经正确、安全的固定。请勿在操作中松开榨汁盖。
8. 插头插入插座或拔除插头前，请检查开关是否处于“0”的位置，以确保操作安全。
9. 使用完毕务必把开关转到“0”的位置上，拆解前务必确定马达已停止转动，否则可能导致机器损伤，甚至人员受伤。
10. 启动机器前必须保证榨汁盖正确固定，否则机器无法正常运转。
11. 请勿令电源线横跨桌子及柜台边缘或接触热表面，避免因电源线损坏导致触电、短路甚至起火。


12. 请勿把机器放在电热炉或其他任何热源附近，否则可能导致机器损伤。
13. 建议连续工作时间不超过5分钟，以避免机器因为过热而起火。
14. 定期清洁机器，可防止灰尘积聚。
15. 请勿擅自拆卸或维修产品。为避免危害，产品需要维修时，请咨询本公司客户服务中心，由指定维修中心维修。

## 操作指南


首次使用:

1. 仔细阅读说明书并保存以备日后查阅。
2. 移除所有包装。  
清洁所有的可拆卸部件，以清除所有制造和加工过程中造成的残留物。


如何组装榨汁机：




1. 把果汁盘装到马达座上。




2. 把不锈钢滤网对准中心放到果汁盘里，紧按滤网边部确保滤网安装到位。  
请勿按压滤网刀片部位，以免被割伤。




3. 安装上盖。



4. 将榨汁盖两侧的扣柄扣到榨汁盖上，然后把扣柄扣进两侧的凹槽中。  
注意：请将扣柄压至垂直的位置，否则榨汁机不会启动。



5. 抓住果渣桶手柄，将果渣桶安放到出渣口下。



6. 将推棒凹槽部位对准入料管凸齿部位，沿入料管推进。



7. 将泡沫挡板从果汁杯的两端突起中滑入，把果汁杯放到出汁嘴下。

## 如何准备需要榨汁的蔬果

1. 清洗干净所需的水果和蔬菜。
2. 去除不能食用的果皮，例如菠萝、香瓜、木瓜等。
3. 剔除蔬果的坚硬的果核，如蜜桃、油桃、樱桃等。
4. 大部分蔬果例如苹果、胡萝卜和黄瓜等不需要切开。过大的蔬果需要先切开，以便放入料口。

## 如何榨汁

1. 组装好榨汁机后，将果汁杯放到出汁嘴下以收集果汁。
2. 把电源插头插到220V的插座中。
3. 根据要榨汁的蔬果类型选择1档或2档。机器启动前请勿放入任何蔬果。软质的蔬果如浆果、香瓜、黄瓜、西红柿等应使用低档榨汁；硬质的蔬果如苹果、芹菜、胡萝卜等应使用高档榨汁。
4. 机器启动后，把食物放进入料管，使用推棒轻轻地将食物向下推。为了达到最佳榨汁效果，请保持缓速下推。  
注意：切勿将手或其他物品伸入料管，必须使用推棒。

5. 在榨汁过程中若果渣桶装满可以将其清空。先把机器关闭，抓住入料口，稍微倾斜榨汁机，然后拿出果渣桶。清空后再重新装上。
6. 泡沫挡板可以阻挡泡沫进入杯中。如果您比较喜欢带有泡沫的果汁，可以从果汁杯中取出泡沫挡板。

#### 提示


1. 在苹果汁中加入少量的柠檬汁可以防止氧化。
2. 请勿用香蕉或鳄梨榨汁，因为它们不含果汁并且会阻塞榨汁机。
3. 让机器多运行一分钟令榨汁机可以榨取更多果汁。
4. 为了方便清洁果渣桶，可在果渣桶上加套一个塑料袋。
5. 榨汁完毕后请尽快拆解并清洗榨汁机。不锈钢刀网/切刀可以浸泡在水中令附着的果渣变松软后再进行清洗。
6. 使用后马上清洗可清洗部件，以避免塑胶部件被某些蔬果染色。

## 清洁及保养


注意：在清洗、拆卸部件时，关上电源开关，拔除电源插头。

### 如何拆卸


注意：拆解机器前，必须确认开关已关闭，电源插头已拔出，马达已停止转动。



1. 从入料口拔出推棒。抓住入料口稍微倾斜机器，然后轻轻的拉开果渣桶



2. 拿开果汁杯，松开榨汁盖两边的扣柄。



4. 取下上盖。扣住滤网边沿轻轻向上提，拆除滤网。
5. 抓住出汁嘴和果汁盘的出渣口边缘轻轻的向上提，拆除果汁盘。

注意：请小心不锈钢滤网上锋利的小刀刃，谨防割伤。

如何清洗

- 1. 开关转到“0”的位置并确认机器完全停止。
- 2. 拔除插头。
- 3. 请参照以上流程拆卸榨汁机。
- 4. 用温热的肥皂水或柔性的洗涤剂清洗果汁盖、果汁杯、推棒、上盖和果汁盘，冲净后晾干。
- 5. 把不锈钢滤网放在流水下，用附带的清洁刷轻轻刷掉滤网和刀片上的果渣。清洁后需将不锈钢滤网放到光亮处，检查滤网孔是否阻塞。如果网孔阻塞，需将滤网浸泡到热水中令附着的果渣松软然后再用尼龙刷清洁。  
注意：滤网底部的刀片非常非常锋利，请小心操作，避免割伤。
- 6. 重新组装机器前请用布或厨房纸巾擦干，以确保机器的干燥。

疑难解答

委托修理前，请仔细阅读该使用说明书后检查以下项目。

现象	处理方法
机器不能运转	产品配备有安全系统。如果部件没有安装妥当，产品将不会运转。请在切断产品电源后，检查部件是否安装正确。
榨汁过程中马达停止转动	关掉榨汁机电源，清理加料管和过滤器，减少添加的物料。
	慢慢压推棒，压下食物时不要过于用力。
	换用高档榨汁。
滤网附着过多的果渣	硬质和软质的蔬果轮流榨汁。
果渣很湿	用低档榨汁。
	关掉榨汁机电源，检查滤网的网孔是否阻塞。如果阻塞，请清洁后再使用。
果汁从上盖边缘漏出	请使用低档榨汁。水分较多的蔬果应使用低档进行榨取。
最初使用设备时，马达装置发出异常气味	初次使用时属于正常现象。如果多次使用后，产品仍会发出此气味，则需检查产品的加工量和加工时间。
机器自动断电	机器连续使用时间过长可能导致机器异常发热，保险丝烧毁，自动断电，保护机器核心部件。需将机器送到博格利佳品牌指定维修点进行检测和维修。
榨汁机噪音很大，发出难闻的气味，机体异常发热，冒烟等	请关闭产品并拔下电源，将机器送到博格利佳品牌指定维修点进行检测和维修。

技术规格参数

型号	BJ-800
额定电压	220V, 50Hz
功率	650W
类型	I
外壳	金属
最长操作时间	30 分钟

执行标准

使用之前，请仔细阅读并妥善保存本说明书。  
该系列产品执行中华人民共和国国家标准：  
GB4706.1-2005,GB4706.30-2008  
本产品按家用标准设计制造，请勿用于商用或工业用途。

果汁食谱

如下是一些方便的食谱。更多的食谱可以从互联网或者从书店的烹饪书籍上获取。

- 1.苹果草莓汁  
5个苹果  
1杯草莓  
苹果和草莓交替榨汁，榨完后马上饮用

2. 苹果蔬菜汁

2个苹果

2个胡萝卜

1棵芹菜主茎

苹果、胡萝卜、芹菜交替榨汁，榨完后马上饮用
3. 蔬菜汁

4个胡萝卜

2盎司（100克）菠菜

一小把欧芹

2棵芹菜主茎

上述配料交替榨汁，榨完后马上饮用
4. 水果&蔬菜混合

1/2个菠萝（去皮）

1个胡萝卜

1个苹果

1棵芹菜主茎

上述材料用榨汁机榨汁后马上饮用
5. 桃子、梨和苹果汁

1个苹果

2个桃子（去核）

1个梨

上述材料用榨汁机榨汁后马上饮用

CONTENTS

15	Product Introduction
15	Product Features
16	Parts Construction
16	Precautions
19	Operation Guide
24	Cleaning and Maintenance
26	Problem shooting
27	Technical Specifications
27	Applicable Standards
28	Juice Recipes




## Product Introduction

Thank you for your purchase and selection and welcome to visit BORGGOO enterprise. BJ-800 high-efficiency juice extractor adopts the special micro-mesh dual layer filter and thus has the dual-extraction-dual-filtration feature, which brings you the maximum volume of juice at ease. The XL feed chute, the extra large capacity and the easy-to-clean construction enable you to make a healthy juice easily.

## Product Features

1. Durable and elegant stainless steel housing
2. Patented unique micro-mesh filter made of stainless steel ensures the dual-extraction-dual-filtration function
3. Juice rate more than 80%, 30% higher than traditional juicers
4. 75mm XL feed chute accommodates whole fruit and vegetables
5. Unique tilt spout angle design pours out maximum volume of juice
6. Two different whirling speeds for juice for both hard and soft fruit separately
7. 1.5 liter large capacity residue container with 700 ml juice container; extra large capacity for convenient use
8. The ergonomic design with removable parts for easy clean
9. Safe and reliable protective device with the automatic shuts off function, extends the life duration
10. With various international and domestic certificate as 3C, GS, CE, CB, CUL

## Parts Construction



- 1-4/6-8 is the removable parts for easy clean
- 5&11 is the non-removable parts
- 9&10 is the operable non-removable parts
- 0= OFF    1= Low speed    2= High speed

## Precaution

Read the instructions carefully and keep for future reference before use of BJ800 high-efficiency juice extractor. To avoid any danger or injury to the operator or any person, basic precautions should be followed including the following.

## Danger

To protect against electrical hazards, do not immerse cord, plugs, or the appliance in water or other liquid.

## Warning

1. This appliance is not recommended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge to avoid any accident.
2. Children should not be allowed to operate this appliance. Close supervision is necessary when this appliance is used around children. Otherwise danger of cut or electrical shock may occur.
3. The cutting blades in the filter basket are sharp. Handle with care when operate or clean the basket to protect against any injury.
4. Always use food pusher to push the fruit/vegetable down the feed chute so to avoid cut injury. If food becomes lodged in the feed chute, use the food pusher to push it down. If this is not possible, turn the motor off and unplug from the outlet and disassemble the unit to remove the stuck food.
5. Do not use the appliance if the cutting blade or filter basket is damaged or otherwise it may cause appliance damage or any other accident.
6. Do not use the appliance with a damaged cord or plug or loose part. It may induce electrical shock, short circuit or fire danger.
7. Do not operate any appliance when it is dropped or damaged in any liquid or otherwise it may result in appliance damage or any other accident. Return the appliance to the service center authorized by BORGOO for checking, servicing and repairing.
8. The appliance adopts the "Y" cord connection. In case of cord damage, Return the appliance to the service center authorized by BORGOO for checking, servicing and repairing to avoid danger.
9. Do not use any accessory not provided or recommended by BORGOO or otherwise it may cause fire, electrical shock or any other injury and your guarantee card will also be invalid.

## Caution


1. Always use this appliance on a dry, level surface.
2. Do not leave unit unattended while in use. It may induce accident.
3. Always turn the appliance off and unplug from the outlet when left unattended or finished using to avoid accident.
4. Do not use the appliance outdoors to protect against quick aging.
5. The appliance is for household use only. Do not use for other than the intended use.
6. Unplug from outlet before putting on or taking off parts and before cleaning so to avoid electrical hazard.
7. Always make sure the juicer cover is clamped securely in place before motor is turned on. Do not unfasten clamps while juicer is in operation.
8. Check that the control is OFF before plugging in or removing the cord from the outlet so to secure the operation safety.
9. Be sure to turn switch to off position after use. Make sure the motor stops completely before disassembling or it may cause appliance damage or person injury.
10. The juice extractor will not operate until the top cover are locked into position
11. Do not let cord hang over edge of table or counter, or touch hot surfaces so to avoid electrical hazard, short circuit, or even fire danger caused by damaged cord.
12. Do not place on or near a electric burner, or any other hot sources. It may damage the appliance
13. Recommended continuous operation duration not more than 5 minutes so to protect against fire danger resulted from appliance overheat.
14. Clean the appliance periodically so to avoid dust accumulation
15. Do not disassemble or repair the appliance randomly. To protect against hazard, consult BORGOO service center for repair by authorized agent.

# Operation Guide


## before first use

1. Read the instructions carefully and keep for future reference.
2. Remove all packaging.
3. Clean all the removable parts to remove any residue left over from the manufacturing process.


## How to assemble the juicer




- 1 . Place the juice bowl onto the motor housing



- 2 . Place the stainless steel filter basket inside the juice bowl.  
Twist the filter basket and gently push down until it is seated in the juicer. To avoid injury, do not press on the cutting blade.




- 3 . Place the juicer cover over the top of the motor housing




4. Lock the juicer cover into position by pressing the side handles until it clicks into the grooves located on both side of the top cover.

NOTE: Unit will not operate if the side handles are not properly fixed on vertical position.



5. Slide the pulp container into position under the pulp chute



6 . Slide the food pusher down the feed chute by aligning the groove



7. Slide the froth separator between the tabs inside the juice container, and place the juice container under the spout.

#### How to Prepare Fruit and Vegetables for Juicing

1. Wash fruit and vegetables. Peel fruits that have inedible skins such as pineapple, melons, papaya, etc.
2. Pit all fruits with hard seeds or stones such as peaches, nectarines, cherries, etc.
3. Most fruits and vegetables such as apples, carrots and cucumber will not need to be cut. If the pieces are too big for the feed chute, slice the fruit or vegetables before starting to juice.

#### How to Juice

1. Assemble the juicer. The juice container or a glass can be placed below the spout to collect juice.
2. Plug the power cord into a 220V power outlet.
3. Choose either '1' speed or '2' speed on the electronic control depending on the type of fruit or vegetable that is being juiced. Never put any fruit or vegetables in the juicer until power is turned on. Soft fruit or vegetables such as berries, melons, cucumber, tomatoes, etc. should be juiced on Lo speed. Harder fruit and vegetables such as apples, celery, carrots, etc. should

be juiced at 'Hi' speed.

4. With the motor running, place food into the feed chute. Using the food pusher, gently guide food down the feed chute. To extract the maximum amount of juice, always push the food pusher down slowly.

Important: do not place hands or foreign objects down the feed chute. Always use the food pusher

5. If the pulp container is full it can be emptied during juicing. Turn the juicer off and remove the pulp container by holding onto the feed chute and tilting the Juicer slightly to disengage the pulp container. Empty the pulp container. Replace the pulp container into position under the pulp chute.
6. The froth separator in the juice container will eliminate froth being poured into the glass. If you prefer to have juice with froth, simply remove the froth separator attachment from the Juice container before juicing.

## Helpful Hints


1. A small amount of lemon juice can be added to apple juice to prevent browning.
2. Do not use bananas or avocados as they do not contain juice and will clog the juicer.
3. Allow the juicer to run for one minute before turning 'OFF' to allow any excess juice to be extracted from the pulp.
4. A plastic bag can be put in the pulp container for easy clean-up.
5. Disassemble the Juicer and rinse off the pulp immediately after juicing. The filter basket can be soaked in water to loosen the pulp. Then wash in warm soapy water.
6. Wash parts immediately after use to avoid discoloration of the plastic parts which may occur with some fruits and vegetables.

## Cleaning and Maintenance


Important: turn off and unplug the plug before cleaning and before assembling or removing part

### How to Disassemble the Juicer


NOTE: Before disassembling the Juicer make sure that the electronic control is in the Off position, the plug has been removed from the wall outlet and the motor has stopped completely



1. Take out the food pusher from the feed chute; then remove the pulp container by holding onto the feed chute and tilting the juicer slightly to disengage the pulp container.



2. Remove the juice container and disengage the side handle



4. Take out the juicer cover, and remove the stainless steel filter basket by lifting up the edge lip.
5. Remove the juice bowl by holding onto the spout and pulp chute outer edge lip.

NOTE: Be careful when handling the stainless steel filter basket as the cutting blades are very sharp.

### How to Clean

1. Rotate the electronic control to the OFF position and wait for the motor to stop completely.
2. Unplug from the wall outlet.
3. Disassemble the Juicer following the directions above-mentioned.
4. Clean the pulp container, juicer cover, food pusher, juice bowl, juice container and forth separator in warm, soapy water. A mild detergent is recommended. Rinse well and dry thoroughly.
5. Hold the stainless steel filter basket under clean running water. Use the cleaning brush included with the Juicer to gently clean away pulp from the filter and cutting blades. Hold the basket up to the light to ensure that the fine mesh holes are not blocked. If the holes are blocked, soak the basket in hot water to loose the pulp and clean with the nylon brush again. Allow to dry on a cloth or paper towel before reassembling the juicer.  
NOTE: The cutting blades are very sharp, handle with care
6. Wipe the appliance with a soft cloth or paper towel to keep the machine dry.

## Problem Shooting

Before entrust for repair ,please read this instruction carefully and check below issues.

Problem	Solution
Juicer will not operate when switched on	The appliance has a safety system, if the parts are not assembled on the right position, the appliance will not operate. Please check the parts whether assemble correctly after unplug.
Motor stalls when juicing	Turn off the appliance, clean the feed chute and stainless steel filter basket, reduce the fruit/vegetable added.
	Push the food pusher down slowly. Do not push the food with too large press.
	Choose High speed instead
Excessive pulp residue attached in the filter basket	Alternately juice soft and hard fruit and vegetables
Pulp too wet	Use Low speed.
	Turn off and check to be sure that the holes in the mesh filter are not blocked. If they are blocked , clean the mesh filter before use.
Juice leaks from the top cover edge area	Use Low speed. Fruits and vegetables with a higher water content should be juiced with Low speed.
Motor emit bad smell in first use	Certain bad smell is normal for first use. If the appliance keeps to give out bad smell after subsequent several use, then check the operation volume and duration
Automatic shut off	The appliance may be overheated after continuous use for excessive period, fuse will open and unit automatically shut off to protect the critical parts. Return the appliance to service center authorized by BORGGO for check and repair.
Excessive noise with bad smell, unit abnormally overheated, smoke	Switch off the unit and unplug from the outlet. Return the appliance to service center authorized by BORGGO for check and repair.

## Technical Specification

Model	BJ-800
Rated voltage	220V,50Hz
Rated power	650W
Type	I
Outer housing	Metal
Maximum operation	30 minutes

## Applicable Standard

Read the instructions carefully and keep for future reference before use

This series of the appliance comply to the National Standards of the People's Republic of China : GB4706.1-2005,GB4706.30-2008

This appliance is designed and manufactured against the household standards, do not use for industrial or business purpose.

## Juice Recipes

Below are a few juice recipes for your convenience. Additional recipes are available on the internet. Recipe books are also available at your local bookstore.

1. Apple Strawberry Juice  
5 Apples  
1 cup strawberries  
Alternate juicing apples and strawberries. Serve immediately
2. Apple Veggie Juice  
2 apples  
2 carrots  
1 stalk celery  
Alternate juicing apples, carrots and celery. Serve immediately
3. Vegetable Juice  
4 Carrots  
2ozs. (100g) Spinach  
1 Small handful of flat leaf parsley  
2stalks celery  
Alternate juicing the above ingredients. Sever immediately.
4. Fruit & Vegetable Cocktail  
1/2 pineapple, peeled  
1 carrot  
1 apple  
1 stalk celery  
Process through juicer and serve immediately
5. Peach, Pear and Apple Juice  
1 Apple  
2 peaches, seed removed  
1 pear  
Process through juicer and serve immediately